



Longueur utile = LU  
Emboîtement = E

Nuttige lengte = NL  
Ineenvoeging = I

$\varnothing$ int. / bin.	80	100	110	130	180	200	230
$\varnothing$ ext. / buit.	130	150	180	200	250	300	350
LU / NL	940	940	940	940	940	940	940
E / I	60	60	60	60	60	60	60
A	140	150	165	175	200	225	250
B	830	830	830	830	830	830	830

Unit of measure: mm

Hekon art. : GTCLV100-T006