



Longueur utile = LU
Emboîtement = E

Nuttige lengte = NL
Ineenvoeging = I

\varnothing int. / bin.	110	130	180	200	230
\varnothing ext. / buit.	180	200	250	300	350
LU / NL	940	940	940	940	940
E / I	60	60	60	60	60
A	165	175	200	230	265
B	830	830	830	830	830

Unit of measure: mm

Hekon art. : GTCLV200-T186