



Longueur utile = LU  
Emboîtement = E

Nuttige lengte = NL  
Ineenvoeging = I

| Ø int. / bin.  | 130 | 180 | 200 | 230 |
|----------------|-----|-----|-----|-----|
| Ø ext. / buit. | 200 | 250 | 300 | 350 |
| LU / NL        | 940 | 940 | 940 | 940 |
| E / I          | 60  | 60  | 60  | 60  |
| A              | 175 | 200 | 230 | 265 |
| B              | 830 | 830 | 830 | 830 |

Unit of measure: mm

Hekon art. : ITCLV200-T906